

# Micro-programmed Control

## Ch 15

Micro-instructions  
Micro-programmed Control Unit  
Sequencing  
Execution  
Characteristics

10/10/2001

Copyright Teemu Kerola 2001

1

## Hardwired Control <sup>(4)</sup>

- Complex
- Fast
- Difficult to design
- Difficult to modify
  - Lots of optimization done at implementation phase

10/10/2001

Copyright Teemu Kerola 2001

2

## Micro-programmed Control <sup>(3)</sup>


- Implement “execution engine” inside CPU
  - execute one micro-instruction at a time
- What to do now?
  - micro-instruction
    - control signals
  - stored in micro-instruction control memory
    - micro-program, firmware
- What to do next?
  - micro-instruction program counter
    - default (?): next micro-instruction
    - jumps or branches?

10/10/2001

Copyright Teemu Kerola 2001

3

## Machine Instructions vs. Micro-instructions



10/10/2001

Copyright Teemu Kerola 2001

4

## Machine Instructions vs. Micro-instructions <sup>(2)</sup>

- Machine instruction fetch-execute cycle produces machine instructions to be executed at CPU
- Micro-instruction fetch-execute cycle produces control signals for data path

10/10/2001

Copyright Teemu Kerola 2001

5

## Micro-program <sup>(4)</sup>



- Stored in control memory
- ROM, PROM, EPROM
- One “subroutine” for each machine instruction
  - one or more micro-instructions
- Defines architecture
  - change instruction set?
  - ⇒ reload control memory

Fig. 15.2

10/10/2001

Copyright Teemu Kerola 2001

6



## Micro-programmed Control Unit <sup>(4)</sup>

- Control Address Register
  - “micro-program PC”
- Control Memory
- Control Buffer Register
  - current micro-instruction
    - control signals
    - next address control
- Sequencing logic
  - select next value for Control Address Reg

Fig. 15.4

10/10/2001

Copyright Teemu Kerola 2001

9

## Micro-programming <sup>(3)</sup>

- Simple design
- Flexible
  - adapt to changes in organization, timing, technology
  - make changes late in design cycle, or even in the field
- Very powerful instruction sets
  - use bigger control memory if needed
  - easy to have complex instruction sets
    - is this good?

10/10/2001

Copyright Teemu Kerola 2001

10

## Micro-programming <sup>(2)</sup>

- **Generality**
  - multiple instruction sets on same machine
  - tailor instruction set to application?
- **Compatibility**
  - easy to be backward compatible in one family
  - many organizations, same instruction set

10/10/2001

Copyright Teemu Kerola 2001

11

## Micro-programming <sup>(2)</sup>

- **Costly to implement**
  - need tools:
    - micro-program development environment
    - micro-program compiler
- **Slow**
  - micro-instruction interpreted at execution time
  - interpretation is internal to CPU
  - interpret one instruction at a time

10/10/2001

Copyright Teemu Kerola 2001

12

## RISC vs. Micro-programming <sup>(8)</sup>

- Simple instructions can execute at very high clock rate
- Compilers can produce micro-instructions
  - machine dependent optimization
- Use only simple instructions and addressing mode
- Keep “micro-code” in RAM instead of ROM
- no micro-instruction interpretation logic needed
- Fast access to “micro-code” in RAM via caching
- Skip instruction interpretation of a micro-program and simply compile directly into lowest language of machine?
- $\Rightarrow$  Compile to “micro-code” and use hardwired control for RISC

10/10/2001

Copyright Teemu Kerola 2001

13

## Micro-program Sequencing <sup>(3)</sup>

- Two address format Fig. 15.6
  - default next micro-instruction address
    - waste of space most of the time?
  - conditional branch address
- One address format Fig. 15.7
  - (Conditional) branch address
- Variable format
  - only branch micro-instructions have addresses
  - waste of time many times?

10/10/2001

Copyright Teemu Kerola 2001

14

## Micro-instruction Explicit Address Generation

- Addresses explicitly present
  - Two-field
    - select one of them
  - Unconditional branch
    - jump to this one
  - Conditional branch
    - select this one or default

10/10/2001

Copyright Teemu Kerola 2001

15

## Micro-instruction Implicit Address Generation

- Addresses not explicitly present
  - Mapping
    - map opcode in machine instruction into micro-instruction address
  - Addition Fig. 15.9
    - higher order bits directly from opcode
    - lower order bits based on current status and tag bits, or fields in current microinstruction
  - Residual Control
    - return from micro-program subroutine

10/10/2001

Copyright Teemu Kerola 2001

16



## Micro-instruction Encoding

- Usually a compromise between pure horizontal and vertical formats
  - optimize on space with encoding multiple signals into a set of fields Fig. 15.11
    - each field defines control signals for certain separate actions
    - mutually exclusive actions are encoded into the same field
  - make design simpler by not using maximum encoding

10/10/2001

Copyright Teemu Kerola 2001

17

## Micro-instruction Encoding (2)

- Functional encoding
  - each field controls some function
    - load accumulator
    - load ALU operands
    - compute next PC
- Resource encoding
  - each field controls some resource
    - ALU
    - memory

10/10/2001

Copyright Teemu Kerola 2001

18

## Example Micro-instruction Sets for a Simple Machine <sup>(3)</sup>

- Micro-instruction types Fig. 15.12
  - 3 register transfers, 2 mem ops, 5 ALU ops, 3 seq. ops
- Vertical format 

type	operation	reg
------	-----------	-----

  - 3 bits for type, 3 bits for operation Fig. 15.12 (a)
  - 2 bits for reg select (max 4 regs)
- Horizontal format 

--	--	--	--	--	--	--	--	--	--

  - 2 bits for reg transfers (3 ops + “none”)
  - 2 bits for mem ops (2 ops + “none”)
  - 2 bits for seq. ops (3 ops + “none”) Fig. 15.12 (b)
  - 3 bits for ALU ops (5 ops + “none”)
  - 2 bits for reg select + 8 bits for constant

10/10/2001

Copyright Teemu Kerola 2001

19

## LSI-11 Single Board Processor



10/10/2001

Copyright Teemu Kerola 2001

20

## LSI-11 (PDP-11) <sup>(5)</sup>

- Three-chip single board processor
  - data chip
    - 26 8-bit regs
      - 8 16-bit general purpose regs,
      - PWS, MAR, MBR, ...
    - 8-bit ALU
      - (at least) 2 passes needed for 16-bit reg ops
  - control chip
  - control store chip Fig. 15.14
    - 22 bit wide control mem for micro-instructions
  - connected by micro-instruction bus Fig. 15.13

10/10/2001

Copyright Teemu Kerola 2001

21

## LSI-11 Micro-instruction Set <sup>(2)</sup>

- Implements PDP-11 instruction set architecture for LSI-11 hardware
  - e.g., PDP-11 16 bit ALU vs. LSI-11 8-bit ALU
- 22 bit wide, extremely vertical set Fig. 15.15
  - 4 bits for special functions
  - 1 bit for testing interrupts
  - 1 bit for “micro-subroutine return”
  - 16 bits for variable format micro-ops
    - jump, cond. branch, literal ops, reg ops
    - ALU, logical, general, I/O ops


Table 15.5

10/10/2001

Copyright Teemu Kerola 2001

22

-- End of Chapter 15 --  
-- Micro-programmed Control --



[http://infopad.EECS.Berkeley.EDU/CIC/die\\_photos/pentium.gif](http://infopad.EECS.Berkeley.EDU/CIC/die_photos/pentium.gif)

10/10/2001

Copyright Teemu Kerola 2001

23

10/10/2001

Copyright Teemu Kerola 2001

24

## Summary <sup>(10)</sup>

- How clock signals cause instruction executions?
- Low level stuff
  - gates, basic circuits, registers, memory
- Cache
- Virtual memory & TLB
- ALU, int & FP arithmetic's
- Instruction sets
- CPU structure & pipelining
- Branch prediction, limitations, hazards, issue
- RISC & superscalar processor
- Hardwired & micro-controlled control


10/10/2001

Copyright Teemu Kerola 2001

25

## Want to Know More?

- Read the text book completely
- 58070-8 Computer Architecture (4 cr)



10/10/2001

Copyright Teemu Kerola 2001

26

