
Memory Hierarchy and Cache Ch 4-5

Memory Hierarchy
Main Memory
Cache
Implementation

12.9.2002 Copyright Teemu Kerola 2002



Goal (4)

- I want my memory lightning fast
- I want my memory to be gigantic in size
- Register access viewpoint:



- data access as fast as HW register
- data size as large as memory

HW solution

- Memory access viewpoint
 - data access as fast as memory
 - data size as large as disk

virtual memory

HW help for SW solution

12.9.2002

Copyright Teemu Kerola 2002

3

Memory Hierarchy (5)

Fig. 4.1

- Most often needed data is kept close
- Access to small data sets can be made fast
 - simpler circuits
- Faster is more expensive
- Large can be bigger and cheaper (per byte)

Memory Hierarchy

up: smaller, faster, more expensive,

more frequent access

down: bigger, slower, less expensive,

less frequent access

12.9.2002


Copyright Teemu Kerola 2002

Principle of locality (7)

(paikallisuus)

- In any given time period, memory references occur only to a <u>small subset</u> of the whole address space

 Fig. 4.2
- The reason why memory hierarchies work



- Average cost is close to the cost of small data set
- How to determine that small data set?
- How to keep track of it?


12.9.2002

Copyright Teemu Kerola 2002

5

Principle of locality (5)

- In any given time period, memory references occur only to a <u>small subset</u> of the whole address space (paikallisuus)
- Temporal locality: it is likely that a data item referenced a short time ago will be referenced again soon (ajallinen paikallisuus)
- <u>Spatial locality:</u> it is likely that a data items close to the one referenced a short time ago will be referenced soon (alueellinen paikallisuus)



12.9.2002

Copyright Teemu Kerola 2002

Memory

- Random access semiconductor memory
 - give address & control, read/write data
- ROM, PROMS

Table 5.1

- system startup memory, (Table 4.2 [Stall99])

BIOS (Basic Input/Output System)

- load and execute OS at boot
- also random access
- RAM
 - "normal" memory accessible by CPU

12.9.2002

Copyright Teemu Kerola 2002

7

RAM

E.g., \$0.12 / MB (year 2001)?

- Dynamic RAM, DRAM
 - simpler, slower, denser, bigger (bytes per chip)
 - main memory?

E.g., 60 ns access

- periodic refreshing required
- refresh required after read
- Static RAM, SRAM E.g., \$0.50 / MB (year 2001)?
 - more complex (more chip area/byte), faster,
 smaller (bytes per chip)
 - cache?

E.g., 5 ns access?

- no periodic refreshing needed
- data remains until power is lost

12.9.2002

Copyright Teemu Kerola 2002

DRAM Access

- 16 Mb DRAM
 - 4 bit data items

Fig. 5.3 (Fig. 4.4 [Stal99])

- 4M data elements, 2K * 2K square
- Address 22 bits

Fig. 5.4 (b) (Fig. 4.5 (b) [Stal99])

- row access select (RAS)
- column access select (CAS)
- interleaved on 11 address pins
- Simultaneous access to many 16Mb memory chips to access larger data items
 - Access 8 bit words in parallel? Need 8 chips.

Fig. 5.5 (Fig. 4.6 [Stal99])

12.9.2002

Copyright Teemu Kerola 2002

9

SDRAM (Synchronous DRAM)

- 16 bits in parallel
 - access 4 DRAMs (4 bits each) in parallel
- CPU clock synchronizes also the bus
 - not by separate clock for the bus
 - CPU knows how longs it takes make a reference – it can do other work while waiting
- Faster than plain DRAM
- Current main memory technology (year 2001)

E.g., \$0.11 / MB (year 2001)

12.9.2002

Copyright Teemu Kerola 2002

RDRAM (RambusDRAM)

- New technology, works with fast memory bus
 - expensive

E.g., \$0.40 / MB (year 2001)?

Faster transfer rate than with SDRAM

E.g., 1.6 GB/sec vs. 200 MB/sec (?)


- Faster access than SDRAM
- E.g., 38 ns vs. 44 ns
- Fast internal Rambus channel (800 MHz)
- Rambus memory controller connects to bus
- Speed slows down with many memory modules
 - serially connected on Rambus channel
 - not good for servers with 1 GB memory (for now!)
- 5% of memory chips (year 2000), 12% (2005)?

12.9.2002

Copyright Teemu Kerola 2002

Flash memory

- Original invention
 - Fujio Masuoka, Toshiba Corp., 1984
 - non-volatile, data remains with power off
 - slow to write ("program")
- Nand-Flash, 1987
 - Fujio Masuoka
 - lowers the wiring per bit to one-eighth that of the Flash Memory's



12.9.2002

Copyright Teemu Kerola 2002

Intel ETOX Flash

- Intel, 1997
- A single transistor with the addition of an <u>electrically</u> <u>isolated polysilicon floating gate</u> capable of storing charge (electrons)
- Negatively charged electrons act as a barrier between the control gate and the floating gate.
- Depending on the flow through the floating gate (more or less than 50%) it has value 1 or 0.
- Read/Write data in small blocks

use high voltage to write, and "Fowler-Nordheim Tunneling" to clear

Floating Gate Stores Electrons

http://developer.intel.com/technology/itj/q41997/articles/art_1.htm


12.9.2002

Copyright Teemu Kerola 2002

13

Intel StrataFlash

- Flash cell is analog, not digital storage
- Use different charge levels to store 2 bits (or more!) of data in each flash cell



12.9.2002

Copyright Teemu Kerola 2002

Flash Implementations

- BIOS (PC's, phones, other hand-held devices....)
- Toshiba SmartMedia, 2-256 MB
- Sony Memory Stick, 2-256 MB
- CompactFlash, 8-512 MB
- PlayStation II Memory Card, 8 MB
- MMC MultiMedia Card, 32-128 MB
- IBM MicroDrive (hard disk!) compatible memory card
- Hand-held phone memories

12.9.2002 Copyright Teemu Kerola 2002 15

Copyright Teemu Kerola 2002

12.9.2002

Cache Memory

(välimuisti)

- Problem: how can I make my (main) memory as fast as my registers?
- Answer: (processor) cache
 - keep most probably referenced data in fast cache close to processor, and rest of it in memory
 - much smaller than main memory
 - (much) more expensive (per byte) than memory
 - · most of data accesses to cache

90% 99%?

Fig. 4.3 & 4.6 (Fig. 4.13 & 4.16 [Stal99])

12.9.2002

Copyright Teemu Kerola 2002

17

Memory references with cache (5)

• Data is in cache?

Hit

Data is only in memory? Read it to cache CPU waits until data available

Miss Fig. 4.5 (Fig. 4.15 [Stall99])

Many blocks (cache lines) help for temporal locality many different data items in cache

Fig. 4.4 (Fig. 4.14 [Stall99])

<u>Large</u> blocks help for <u>spatial</u> locality lots of "nearby" data available

Fixed cache size? Select "many" or "large"?

12.9.2002 Copyright Teemu Kerola 2002

Cache Features (6)

- Size
- Mapping function

(kuvausfunktio)

- how to find data in cache?
- Replacement algorithm

(poistoalgoritmi)

- which block to remove to make room for a new block?
- Write policy

(kirjoituspolitiikka)

- how to handle writes?
- Line size (block size)?

(rivin tai lohkon koko)

• Number of caches?


12.9.2002

Copyright Teemu Kerola 2002


19

Cache Size

- Bigger is better in general
- Bigger may be slower
 - lots of gates, cumulative gate delay?
- Too big might be too slow!




1KW (4 KB), 128MW (512 MB)?



12.9.2002

Copyright Teemu Kerola 2002





$Mapping_{\ (2)}$


- Given a memory block address,
 - is that block in cache?
 - where is it there?
- Three solution methods
 - direct mappings
 - fully associative mapping
 - set associative mapping


12.9.2002

Copyright Teemu Kerola 2002









Fully Associative Mapping

- Lots of circuits
 - tag fields are long wasted space!
 - each cache line tag must be compared simultaneously with the memory address tag
 - · lots of wires

• lots of comparison circuits

Large surface area on chip


- Final comparison "or" has large gate delay
 - did any of these 64 comparisons match?


 2 log(64) = 8 levels of binary gates


- how about 262144 comparisons? _{18 levels?}
- \Rightarrow Can use it only for small caches

12.9.2002

Copyright Teemu Kerola 2002









Two definitions for "Set" in "Set Associative Mapping"

- Term "set" is the set of all possible locations where referenced memory block can be
 - Field "set" of memory address determines this set
 - [Stal03], [Stal99]
- Cache memory is split into multiple "sets", and the referenced memory block can be in only one location in each "set"
 - Field "index" of memory address determines possible location of referenced block in each "set"
 - [HePa96], [PaHe98]

12.9.2002

Copyright Teemu Kerola 2002





Set Associative Mapping

- Set associative cache with set size 2
 - = 2-way cache
- Degree of associativity v? Usually 2
 - v large?

Fig. 7.16 [PaHe98]

- More data items (v) in one set
- · less "collisions"
- final comparison (matching tags?) gate delay?
- v maximum (nr of cache lines)
 - \Rightarrow fully associative mapping
- v minimum (1) \Rightarrow direct mapping

12.9.2002

Copyright Teemu Kerola 2002

Replacement Algorithm

- Which cache block (line) to remove to make room for new block from memory?
- Direct mapping case trivial
- First-In-First-Out (FIFO)
- Least-Frequently-Used (LFU)
- Random
- Which one is best?
 - Chip area?
 - Fast? Easy to implement?

12.9.2002

Copyright Teemu Kerola 2002

35

Write Policy

- How to handle writes to memory?
- Write through

(läpikirjoittava)

- each write goes always to memory
- each write is a cache miss!

(lopuksi kirjoittava takaisin kirjoittava?)

- Write back
 - write cache block to memory only when it is replaced in cache
 - memory may have stale (old) data
 - cache coherence problem (välimuistin

(välimuistin yhteneväisyysongelma)

12.9.2002

Copyright Teemu Kerola 2002

Line size

- How big cache line?
- Optimise for temporal or spatial locality?
 - bigger is better for spatial locality
- <u>Data</u> references and <u>code</u> references behave in a different way
- Best size varies with <u>program</u> or <u>program phase</u>
- 2-8 words?
 - word = 1 float??

12.9.2002

Copyright Teemu Kerola 2002

37

Number of Caches (3)

- One cache too large for best results
- Unified vs. split cache

(yhdistetty, erilliset)

- same cache for data and code, or not?
- split cache: can optimise structure separately for data and code
- Multiple levels of caches
 - L1 same chip as CPU
 - L2 same package or chip as CPU
 - older systems: same board

Fig. 4.13


L3 - same board as CPU

(Fig. 4.23 [Stal99])

12.9.2002

Copyright Teemu Kerola 2002

-- End of Ch. 4-5: Cache Memory --



http://www.intel.com/procs/servers/feature/cache/unique.htm

"The Pentium® Pro processor's unique multi-cavity chip package brings L2 cache memory closer to the CPU, delivering higher performance for business-critical computing needs."

12.9.2002 Copyright Teemu Kerola 2002 39